

The TENAK LabLogger starter Kit TE62000:

- One LabBird (A)
- Two Labloggers (B)
- One Door contact (C)
- One PT100/1000 converter (D)
- One PT100 probe (E)

